LOFT Installation Instructions for LOFT in Drywall

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING. RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN. ALL INSTALLS SHOULD BE IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTIRCAL CODES. ALL WIRES AND MATERIALS USED FOR INPUT/OUTPUT MUST BE UL APPROVED.


> Fixture Drywall Flange Kit Safety Wire

TALLING. INSTALLED IN ECTIRCAL TPUT	Fixture Dimensions	
	Product	Dimensions
	LOFT	2x2, 2x4, 1x4
Provided Hardware:		


ARON

Light Delivered[™]


Fixture Installation Steps for Drywall:




Cut hole in drywall ceiling for fixture and flange kit. hole size: 24.6in x 24.6in Save cutout drywall to fill in top of fixture if desired.



Install fixture into ceiling by resting ontop of the previously installed flange kit.



Assembly flange kit using two screws per corner and install into ceiling.




A Remove access plate and install BX connector through the knock-out. Connect wires from the BX cable to wires on driver using wire nuts. If dimmer is required, connect appropriate wires to grey/purple wires on the driver. Ensure power supply is properly grounded and connections comply with local and national codes.







6 Attach safety wire to Loft fixture and structure if needed.



- Cut excess drywall or ceiling tile to (Tegular/Flat): a. 2x2 Single Light Engine Fixture: 20.00"x 23 3/4""
- b. 2x4 fixture: 20.00" x 47 3/4""
- c. 1x4 fixture: 8 1/4" x 47 3/4"
- d. 2x2 Dual Light Engine Fixture: 15 1/2" x 23 3/4"
- e. 2x4 Dual Light Engine Fixture: 15 1/2" x 47 3/4"



Place the cut drywall/ceiling tile on the top of the fixture to complete installation.

